

Table 4 Approximate Battery Dive Time on Default Settings depending on Months of Storage in the unit
(ER14335M Battery/ ER17335M Battery).

Months inside the unit	Dive time
1	28h/ 60h
2	21h/ 48h
3	14h/ 36h
4	7h/ 24h
5	0h/ 12h
6	0h/ 0h